



*750 Airport Road • Lakewood, New Jersey 08701 USA*

The MaxFlight Operator Training program is outlined to give you a quick overview of the unit along with a basic understanding of how the unit works.

Ensure you use the Operator Manual during the training as it gives specific procedures and guidelines.

Please make sure that all personnel are familiar with and have actually accomplished the “Emergency Manual leveling and Lowering” procedure and the “Emergency Raise Procedure”.

If there are any questions, please feel free to call the Technical Support Division at (732) 942-9898, ext. 235 or 300.